



Fuel Water Remover

Bardahl Fuel Water Remover is a concentrated blend of special additives that act to dissolve water in petrol and diesel fuel; allowing it to be burnt away during the normal combustion cycle.

The problem

By various means water can be present in fuel due to incorrect or bad storage, leaking tanks, poor fitting or replacement filler caps and leaks within the vehicles own fuel system. Condensation due to climatic changes can also be result in the presence of moisture. Water is not mixable with fuel and by collecting in fuel filters, injectors or carburetor jets it's presence can effect the smooth operation of an engine leading to erratic or 'lumpy' tick over, poor acceleration and increased fuel consumption.

The action

Bardahl Fuel Water Remover used regularly emulsifies water present in fuel allowing it to pass through the system and be burnt away in the combustion chamber by the normal combustion cycle. Removing water from the fuel tank, filter and system prevents corrosion, reduces both 'pinging' and misfire allowing improved performance and fuel economy.

Product properties

- Eliminates water from petrol and diesel fuel.
- Protects the fuel system (injection or carburetor).
- Makes cold starting easier and protects the engine from corrosion.
- Prevent the blocking of fuel injectors and the freezing of carburetors or fuel filters due to moisture.
- Prevents and reduces the formation of rust.

Directions for use

Every eight weeks or as required pour one bottle into the fuel tank before filling with fuel. This procedure will allow complete mixing of the fuel with the additive and will treat up to 60 litres. **Bardahl Fuel Water Remover** can be used for petrol and diesel fuel. Safe to use with catalytic converters.

Article number	1082
Contents	300 ml